

Air conditioner

User manual

Wireless Remote Control AR-EC03E/EH03E/EC03M/EH03M

- Thank you for purchasing this Samsung Product.
- Before operating this unit, please read this manual carefully and retain it for future reference.



DB68-07614A-03

SAMSUNG

Contents

Safety Information	3
Safety Information	3
At a Glance	5
Preparation	5
Checking the package contents • Inserting batteries • Installing the remote control holder	5
Remote Control Operation	6
Operation modes • Controlling temperature • Controlling fan speed • Controlling air flow direction	6
Power Smart Features	7
Cooling Operation	7
Cool mode • WindFree Cooling function	7
Dehumidifying Operation	9
Dry mode	9
Air Purifying Operation	9
S-Plasma Ion function	9
Heating Operation	10
Heat mode (compatible model: AR-EH03E/EH03M)	10
Quick Smart Features	10
Auto mode • Fan mode	10
Turbo function • Quiet function • Long reach function • Beep sound function • Display lighting function	11
Controlling the indoor units individually • Clean function • Clearing the filter-cleaning reminder	12
Controlling the air flow direction individually • Wi-Fi Function	13
Motion Detection Feature	14
Indirect function with Motion detection feature • Direct function with the Motion detection feature	14
Energy-Saving Operation	14
Timed on/Timed off function	14
good'sleep function	15

Safety Information

This content is intended to protect the user's safety and prevent property damage. Please read it carefully for correct use of the product.



WARNING

Hazards or unsafe practices that may result in severe personal injury or death.



CAUTION

Hazards or unsafe practices that may result in minor personal injury or property damage.



Follow directions.



Do NOT attempt.



Make sure the machine is grounded to prevent electric shock.



Unplug the appliance.



Do NOT disassemble.

FOR INSTALLATION



WARNING



The installation of this product must be performed by a qualified technician.

- Failing to do so may result in electric shock, fire, product malfunction, explosion, or injury.



Do not install this product near a heater, or inflammable material. Do not install this product in a humid, oily or dusty location, in a location exposed to direct sunlight and water (rain drops). Do not install this product in a location where gas may leak.

- Failing to do so may result in electric shock or fire.



CAUTION



Install the product on a hard and level place that can support its weight.

- If the place cannot support its weight, the product may fall down and it may cause product damage.

Safety Information

FOR OPERATION



WARNING



If the product generates a strange noise, a burning smell or smoke, unplug the product immediately and contact your nearest service centre.

- Failing to do so may result in electric shock or fire.



Do not attempt to repair, disassemble, or modify the product yourself.

- Failing to do so may result in electric shock, fire, product malfunction, or injury.



CAUTION



Do not allow water to enter the product.

- Failing to do so may result in fire or explosion.



Do not operate the product with wet hands.

- Failing to do so may result in electric shock.

Do not spray volatile material such as insecticide onto the surface of the product.

- As well as being harmful to humans, it may also result in electric shock, fire, or product malfunction.

Do not give a strong impact to the product and do not disassemble the product.

After replacing remote control batteries, make sure to keep the old batteries out of reach of children.

- If your child has swallowed a battery, immediately contact a doctor for assistance.

When replacing batteries, exercise caution to ensure that your skin does not come into contact with battery liquid.

- Battery liquid is harmful to the human body.

Do not use this product for other purposes.

- This product is designed to be used only for a system air conditioner.

Do not press the buttons with any sharp objects.






- Failing to do so may result in electric shock or part damage.

Do not clean the product by spraying water directly onto it. Do not use benzene, thinner, alcohol or acetone to clean the product.


- Failing to do so may result in discoloration, deformation, damage, electric shock, or fire.


Preparation

Checking the package contents


Item	Quantity	Shape
Wireless remote control	1	
Battery (AAA 1.5 V)	2	
M4 x L16 screw	2	
Remote control holder	1	
User Manual	1	

Inserting batteries



- If the  (Low battery) indicator appears on the remote control display, replace the batteries with two new AAA 1.5V batteries.

Installing the remote control holder



- 1 Choose a location on the wall where to install the remote control holder.
- 2 Mark the two spots for fastening the two M4 x L16 screws. Then drill the two holes.
- 3 Fasten the screws through the holes to fix the remote control holder in place.


NOTE

- Installation location requirements:
 - Avoid locations exposed to direct sunlight.
 - Avoid locations where the holder is covered by objects such as curtains.
 - Choose a location that is at least 1 m away from a TV or stereo system.
- If the remote control will not be used for an extended period of time remove the batteries and store them separately.

Remote Control Operation

You can use the air conditioner easily by selecting a mode and then by controlling the temperature, fan speed, and air flow direction. For remote control buttons related to each operation, see the pages at the front of this manual.

1 Operation modes

You can change the current mode between Auto, Cool, Dry, Fan, and Heat by pressing the  button.

1 Controlling temperature

You can control the temperature in each mode as follows:

Mode	Temperature control
Auto/ Cool/ Dry	Adjust by 1 °C (1 °F) between 18 °C (65 °F) and 30 °C (86 °F).
Fan	You cannot control the temperature.
Heat	Adjust by 1 °C (1 °F) between 16 °C (61 °F) and 30 °C (86 °F).

You can switch between Celsius and Fahrenheit indications on the remote control.











▶ Press and hold for 3 or more seconds.

NOTE

- The temperature indications on the indoor unit are not switched.
- This function is canceled when the remote control batteries are replaced. In this case, run this function again.

1 Controlling fan speed

You can select the following fan speeds in each mode:




Mode	Available fan speeds
Auto/ Dry	 (Auto)
Cool/ Heat	 (Auto),  (Low),  (Med),  (High)
Fan	 (Low),  (Med),  (High)







1 Controlling air flow direction

You can change air flow direction to either vertical or horizontal.

In operation ▶  or 

NOTE

- To lock a specific air flow direction, press either the  or  button when the air flow blades are in the intended position.
- Duct-type indoor units do not come with a vertical air flow direction.
- If you press the  button on a 360-cassette indoor unit, the indicator display of indoor unit changes as follows.

Press count	Controlling air flow direction	Indicator
1	Swing	
2	Spot	
3	Swing	
4	Mid	
5	Swing	
6	Wide	

※ The indication may vary depending on the previously used mode.

- The individual air flow direction control function, which is available on the 360 cassettes only, can be operated with a 360-cassette wireless remote control (AR-KH00E, AR-KH00U) only.

Cooling Operation

The smart and powerful cooling functions of the Samsung air conditioner keep an enclosed space cool and comfortable.

2 Cool mode

Use the Cool mode to stay cool in hot weather.




NOTE


- For comfort, keep the temperature difference between the indoor and outdoor air within 5°C (9°F) in the Cool mode.
- To cool your room quickly, select a low temperature and a high fan speed.
- To save energy, select a high temperature and a low fan speed.
- As the indoor temperature approaches the set temperature, the compressor will operate at a low speed to save energy.

3 WindFree Cooling function

Use the WindFree Cooling function to enjoy mild cool breeze exuding from fine holes on the WindFree panel with the air flow blade closed, instead of getting cool wind directly. The automated control of the temperature and fan speed according to the indoor temperatures keeps your room cool and pleasant.



NOTE

- To cancel this function, press the  button again.
- If the WindFree Cooling function is cancelled, the air conditioner returns to the original fan speed.
- You can adjust the set temperature during the WindFree Cooling function, and recommended set temperatures are 24 to 26 °C (75 to 79 °F). However, you cannot change the set temperature in the Fan mode.
- You can use the WindFree Cooling function when the Cool, Dry, or Fan mode is running.
- If the room temperature goes high because of rise of external temperature, heat from cooking, or other reason, operate the WindFree Cooling function after operating in the Cool mode.
- If you select the WindFree Cooling function in the Fan mode, the compressor stops working so that cool air does not come out. However, mild breeze comes out and starts to clean the air in the room.

Cooling Operation

- During the WindFree Cooling operation, the cold air may be intermittently weakened depending on the temperature and humidity in the room. But the WindFree air currents are maintained and the weakened cold air is immediately recovered, consequently keeping the room comfortable. (During the WindFree Cooling operation, the air flow blades may open to control the indoor air currents smoothly, depending on the installation settings. In this case, as soon as the indoor temperature and humidity change, the air flow blades are closed and the WindFree Cooling operation restarts. For more information on the installation settings, see "Setting the indoor unit addresses and the installation options" in the installation manual of the indoor unit.)

Change of the air flow blade by temperature and humidity			
Indoor temperature and humidity	Low	High	
		Breeze is blown via the micro holes on the air flow blades	Breeze is blown via the micro holes on the air flow blades
Air flow blade	Closed	Closed (default)	Opened (according to setting)

- When the WindFree Cooling function runs while sleeping, you may feel cold air if the air conditioner is installed over the bed. In this case, set the desired temperature higher than the normal setting temperature.
- If you select the WindFree Cooling function while such functions as Turbo, Quiet, Long reach, an Air flow direction (⌚, ⌚) or good'sleep are running, these functions are cancelled.

Dehumidifying Operation

The dehumidifying function of the Samsung air conditioner keeps an enclosed space dry and comfortable.

4 Dry mode

Use the Dry mode in rainy or humid weather.



NOTE

- You cannot change fan speed in the Dry mode.
- The greater the difference between the set temperature and the current temperature is, the greater the amount of air that is dehumidified is.

Air Purifying Operation




The air purification function of the Samsung air conditioner keeps the air in an enclosed space purified.

5 S-Plasma Ion function

Use the S-Plasma Ion function to purify your room with negative ions produced by the air conditioner. This function is available in the Auto, Cool, Dry, Fan, and Heat modes.



NOTE

- To cancel the S-Plasma Ion function, press the  button again.
▶ 
- When the S-Plasma Ion function is additionally selected in the Fan mode, you cannot change the set temperature.
- If air conditioning and S-Plasma Ion functions are on and you want to stop both functions, press  on the air conditioner.
- When the S-Plasma Ion function is additionally selected while a specific mode is running, there is little difference in electricity consumption and operating noise.

Heating Operation

The heating functions of the Samsung air conditioner keep an enclosed space warm and comfortable.

6 Heat mode (compatible model: AR-EH03E/EH03M)

Use the Heat mode to stay warm.



NOTE

- While the air conditioner warms up, the fan may not operate for a while at the beginning to prevent cold wind.
- While the defrost function is running, the indoor unit provides no breeze to prevent cold wind.

- If the outdoor temperature is low and the humidity is high while the Heat mode is running, the heating performance of the air conditioner may decrease due to frost and ice that formed on the outdoor heat exchanger. When this condition happens, the air conditioner runs the defrost function for about 5 to 12 minutes to remove the frost and ice, and water steam is released from the outdoor unit.
- The operation time of the defrost function varies depending on the amount of the frost and ice and the humidity.
- While the defrost function is running, none of other functions will work, even if you select them on the remote control.

Quick Smart Features

There is a variety of useful functionality provided by the Samsung air conditioner.

7 Auto mode

Use the Auto mode when you want the air conditioner to automatically control the mode (Heat or Cool). The air conditioner will provide the most comfortable atmosphere that it can.



NOTE

- You cannot change the fan speed.
- While the Cool mode is running, the air conditioner produces a strong cold air if there is a large difference between the set temperature and the current temperature. When the temperature difference becomes small, the air conditioner automatically changes the air flow direction to Wide and keeps the room at a comfortable temperature.

8 Fan mode

Use the Fan mode to run the air conditioner like a common fan. The air conditioner provides a natural breeze.




NOTE

- If the air conditioner will not be used for an extended period of time, dry the air conditioner by running it in the Fan mode for 3 or 4 hours.

Quick Smart Features

9 Turbo function

Use the Turbo function to provide intensive cooling or heating to sharply decrease or increase indoor temperature within 30 minutes.




NOTE

- After 30-minute operation, the air conditioner automatically switches to standard the Cool or Heat mode.
- You can change air flow direction. Duct-type indoor units do not come with a vertical air flow direction.
- You cannot change set temperature or fan speed.
- If you select the Turbo function while such functions as WindFree Cooling, Quiet, Long reach or good'sleep are running, these functions are cancelled.

10 Quiet function

Use the Quiet function to reduce operating noise. You can select this function both in the Cool and Heat modes.




NOTE

- You can change set temperature and air flow direction.
- You cannot change the fan speed.
- If you select the Quiet function while such functions as Turbo, Long reach or good'sleep are running, these functions are cancelled.

11 Long reach function

Use the Long reach function to deliver strong air flow that quickly reaches a far distance.



NOTE

- You cannot change the fan speed.
- If you select the Long reach function while such functions as WindFree Cooling, Turbo, Quiet or good'sleep are running, these functions are cancelled.


12 Beep sound function

Use the Beep sound function to turn on or off the beep sound that plays when you press a button on the remote control.



13 Display lighting function


Use the Display lighting function to turn on or off the Air purity level lighting indicator of the indoor unit.



Quick Smart Features

14 Controlling the indoor units individually

Use the Zone function to choose the indoor unit you want to operate individually. For example, select Zone 1 to control only the indoor unit 1.



NOTE

- You can select either one or all of **Zone 1 to Zone 4**.
- The indoor unit numbers must be set by the installer: the installer sets a number on each indoor unit. To change the existing indoor unit numbers, contact a service centre.
- The current Zone function settings persist even if you change the current mode or you turn off and then turn on the remote control. The zone selection you made using the remote control is reset when the remote control batteries are replaced.

15 Clean function

Use the Clean function to remove moisture from the inside of the air conditioner for preventing propagation of fungi, bacteria, etc.




NOTE

- Depending on the condition of the indoor unit, the Clean operation stops after running for 30 seconds to 20 minutes.
- When the Clean function is set, the Timer LED on the indoor unit blinks 3 times for 3 seconds (OFF → ON → OFF → ON → OFF → ON → OFF → returns to the previous state). When the Clean function is cancelled, the Timer LED on the indoor unit blinks once for 1 second (OFF → ON → OFF → returns to the previous state).
- If you turn on the air conditioner and then turn it off within 20 seconds, the Clean function does not operate.
- When the air conditioner is turned off, the Clean function operates immediately. When it is turned on, the Clean function operates after it is stopped.
- Once the Clean function is started, it automatically continues to operate until it is cancelled.


16 Clearing the filter-cleaning reminder

Use the Filter Reset function to reset the filter-cleaning reminder after cleaning or replacing the filter.





17 Controlling the air flow direction individually

Use the individual air-flow-direction control function to individually control the air flow directions of the air outlets.



NOTE


- This function is available only on 4-way cassette air conditioners.
- You can select all or specific blades of indoor units 1 through 4.
- To cancel the selected air flow direction, press the  button.
- If specific blades are selected, the  button is disabled.
- The individual air flow direction control function, which is available on the 360 cassettes only, can be operated with a 360-cassette wireless remote control (AR-KH00E, AR-KH00U) only.

18 Wi-Fi Function

Use the Wi-Fi Function to turn on or off the Wi-Fi for the indoor unit in which the Wi-Fi Single is installed.



NOTE


- For more information on the connection of Wi-Fi Single to the SmartThings app, refer to the Wi-Fi Single manual.
- The default setting for Wi-Fi Single is Wi-Fi On.
- When you turn on or off the Wi-Fi function, the  (Transmit) indicator blinks.

Motion Detection Feature

To use the Motion detection feature, the air conditioner must be equipped with a Motion Detection Kit, which is sold separately. If the Motion Detection Kit is already installed, the motion detection feature must be enabled so that it can operate normally. (For more information, refer to the Motion Detection Kit manual.) When **Direct** or **Indirect** is displayed on the remote control display, the Motion detection feature changes the air conditioner to energy-saving mode if there are no people in the room.

19 Indirect function with Motion detection feature

Use the Indirect function to get an indirect wind so that you can feel comfortable. When this function is turned on, the air conditioner detects people and blows air indirectly around them.




NOTE

- When the Indirect function is set simultaneously with the Auto, Dry, Fan, WindFree Cooling, Turbo, Quiet, Long reach, air flow direction (↻, ↺) or good'sleep function, **Indirect** is displayed on the remote control display but this function does not operate.

20 Direct function with the Motion detection feature

Use the Direct function to get a direct wind so that you can feel comfortable. When this function is turned on, the air conditioner detects people and blows air directly toward them.



NOTE


- When the Direct function is set simultaneously with the Auto, Dry, Fan, WindFree Cooling, Turbo, Quiet, Long reach, air flow direction (↻, ↺) or good'sleep function, **Direct** is displayed on the remote control display but this function does not operate.
- The Direct function is not supported by MCR-SMA model.

Energy-Saving Operation

The Samsung air conditioner provides functions that allow you to reduce electricity consumption.

21 Timed on/Timed off function



Use the Timed on/Timed off to turn on or off the air conditioner after the time that you set.



- Press the (Timer) button to change the current function between On, Off, and (good'sleep). (good'sleep) is displayed in the Cool and Heat mode only.

NOTE


- You can set a time between 0.5 and 24 hours. Set the time interval to 0.0 to cancel the Timed on/off function.
- After starting the Timed on function, you can change the mode and the set temperature. When you apply the Timed on/off function to the Fan mode, you cannot change the set temperature.



- You cannot set the same time for both of the Timed on and Timed off functions.
- If you press the  button when the remote control is off, **On** is displayed first on the remote control display; if you press the  button when the remote control is on, **Off** is displayed first.

Combining Timed on and Timed off	
When the air conditioner is off	<p>Example) Timed on: 3 hours, Timed off: 5 hours</p> <ul style="list-style-type: none"> The air conditioner turns on after 3 hours from the moment you start Timed on/off, remains on for 2 hours, then turns off automatically.
When the air conditioner is on	<p>Example) Timed on: 3 hours, Timed off: 1 hours</p> <ul style="list-style-type: none"> The air conditioner turns off after 1 hour from the moment you start Timed on/off, then turns on after 2 hours from the moment it is turned off.

22 good'sleep function

Use the good'sleep function to get a good sleep at night and to save energy. You can select this function in the Cool mode.



- Press the  (Timer) button to change the current function between On, Off, and  (good'sleep).

NOTE

- Fan speed and air flow directions are automatically adjusted.
- You can adjust the set temperature by 1 °C (1 °F) between 18 °C (65 °F) and 30 °C (86 °F).
- The recommended set temperature in good'sleep function is 25 to 27 °C (77 to 81 °F).
- You can set the operation time to between 0.5 and 12 hours. Set the operation time to 0.0 to cancel the good'sleep function.
- The default operation time for the good'sleep function in the Cool mode is 8 hours. If the operation time is set to over 5 hours, the Wake up function begins 1 hour before the set time. The air conditioner stops automatically when the operation time expires.
- When the Timed on, Timed off, and good'sleep functions are overlapped, the air conditioner operates its timer with only the function that you have started most recently.
- If you select the good'sleep function while such functions as WindFree Cooling, Turbo, Quiet, Long reach are running, these functions are cancelled.

Memo



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

(For India only)

For more information on safe disposal and recycling, visit our website www.samsung.com/in/support or contact our Helpline numbers - 1800 40 SAMSUNG (1800 40 7267864)
1800 5 SAMSUNG (1800 5 7267864).



Correct disposal of batteries in this product

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66.

This product is India RoHS compliant

